



Email - sales@tv4rv.com

## REPLACING THE Z60-2848I TRIPOD HINGE

The Phillips screws that hold the tripod leg to the hinge are often very tight and require care when removing. Use a #3 Phillips screwdriver and bear down hard when turning the screwdriver to avoid stripping the head. We include new screws with the hinge in case they are needed.