



TV 4 RV.com

QUALITY PRODUCTS MADE BY RVers for RVers

Email - sales@tv4rv.com – Phone - 541-244-0250

Assembling the DirecTV Slimline Satellite Dish

STEP 1 – Mount the AZ-EL fixture onto the tripod mast or similar 2” post to support it during assembly.



STEP 2 – Attach the Tilt Plate to the AZ-EL fixture using 3 stove bolts and either hex nuts or T knobs as provided.



STEP 3 – Attach the LNB arm to the tilt plate using the hex bolts provided. Your model arm may be slightly different than the one shown. If not installed, put the RG-6 cable(s) into the LNB arm. If our Folding LNB Arm Kit has been installed, remove the two bolts, install the cable(s) and replace the bolts by installing them OVER the cable(s).

STEP 4 – Attach the Dish Face to the Tilt Plate using the Four painted stove bolts and hex nuts.



STEP 5 – Complete the assembly by installing the LNB head and fastening with either screws and nuts provided or using the clamp on the end of the LNB arm.